

# Installation Instruction

1. Please tighten the screws of the upper-mount.
  2. Put the spring seat(C) and spring(E) in the fixed position of the car.
  3. Compress the spring by the mini adjustable elevator,  
no matter too tight or loose will result in unusual sound or damage to the shock absorber.  
5Kg-: The spring should be compressed to 20-25mm  
5Kg +: The spring should be compressed to 15-20mm.
  4. Tighten the screw after rotating the bracket to let(B) parallel the screw of the car.
  5. Finally, Tighten (D) and rotate (A) clockwise to tighten.
- \* Whenever adjust the ride-height of the shock absorber, must to fix the spring perch(C) and compress the spring (as step 3) firstly, then redo step 4 & 5.

For example:

